



ELITE DASH

QUICK SYSTEM GUIDE

FEEL THE DIFFERENCE LIKE A REAL ELITE



contact@elitedash.ae



TABLE OF CONTENTS:

Supported ECU's	02	Vehicle	11
Introduction	03	Themes	12
Why Choose EliteDash	03	Keypad	13
How To Use EliteDash	04	Keypad Edits	14
How To Connect EliteDash	05	Gauge Customization	15
Engine	06	Color Slider	16
Connection	07	Settings	17
Gears	08	Edit View & Quick Settings	18
Fuel	09	System Setting	19
Tires and Wheels	10	Shortcut Buttons	20



SUPPORTED ECUS:

COMPATIBLE WITH ANY ECU AFTERMARKET OR FACTORY, VIA CAN!

» MaxxECU

» ECUMaster

» MoTeC

» GM ECU

» Syvecs

» Emtron

» Haltech

» AEM

» Link ECU

LEGAL DISCLAIMER:

Elite Dash products are intended for motorsport, off-road, and professional installation use. All performance modifications and installations are undertaken at the customer's own risk. Products must be installed and used in accordance with Elite Dash instructions and all applicable local laws and regulations. To the maximum extent permitted by law, Elite Dash is not liable for any loss or damage arising from improper installation, modification, misuse, or use outside the product's intended purpose. This disclaimer does not exclude or limit any warranty or liability that cannot be excluded under applicable law. © 2026 Elite Dash Technology. All rights reserved.



INTRODUCTION:

Our Elite screens provide a high definition display that exclusively includes EliteDash application. It allows you to track the vehicle's CAN data and enjoy displaying our luxury themes while driving your vehicle. Ultimately, EliteDash has the perfect vehicle automotive application for road trips, streets and race tracks.

WHY CHOOSE ELITEDASH:

- » Its powerful system performs multiple tasks at a time.
- » The display touch screen with quick response.
- » Keep you alert about all sensors connected to ECU.
- » Customize your themes with names, logos, and pictures.
- » Multicolor sliders.
- » Easy installation.



HOW TO USE ELITEDASH:

Note: Wi-Fi is required for first login only.

- 1** Send an email to contact@elitedash.ae they will create an account for you and verify within 24 hours
- 2** Once your account is created, go to the elitedash screen and enter your registered email id and password, then press the "LOG IN" button as shown in the image below.



E-12



HOW TO CONNECT YOUR VEHICLE ECU TO ELITEDASH:

1 Once you are logged in the following home page will appear on your screen.

2 Press on the **Top middle of the screen** the menu bar will show.



3 Press the **"DASH SETTINGS"** button on the left following page will appear on your screen.

Note: There are different functions available under the Garage section. Each of them is discussed next page.





ENGINE:

- 1 Click the **"ENGINE"** option it shows the details about the engine installed in the vehicle e.g., engine type, Max RPM, Distance between services, etc.
- 2 You can choose the desired RPM you want the Lights to show in warning or critical the difference between RPM warning and Critical is that RPM warning is Orange color and Critical is RED color.
- 3 To adjust the RPM warning, click on it and adjust the value to your likings same to the RPM critical



CONNECTION:

- 1** Press the **"CONNECTION"** option to view the current list of data sources.
- 2** Press **"ADD"** to create a new connection for a specific ECU.
- 3** Once you tap, a list of available sources will appear. Select the source you want to use from the list.




GEARS:

1 Press on the **"GEARS"** option under the "Garage" tab the following page will appear on your screen.

2 Under the **"GEARS"** section, enter your gear ratio for each gear.

3 Or press **"Calibrate Gears"** to match with the vehicle's actual gear positions.



FUEL:

1 Press the **"FUEL"** option the following page will appear on your screen.



2 Select the fuel type in the settings: Gasoline or Diesel. Each option uses the appropriate AFR.

3 Enter the fuel capacity of your car.



TIRES AND WHEELS:

- 1 Press the **"TIRES AND WHEELS"**, the following page will appear on your screen.
- 2 Enter the tire width, tire aspect, and wheel diameter.
- 3 Enter the Pressure Warning Limit to set the tyre pressure alert threshold. Set the value to 0 to disable the TPMS.



VEHICLE:



- 1 Press on the **"VEHICLE"** option the following page will appear on your screen.
- 2 Enter vehicle name, vehicle weight, odometer in km, trip fuel consumption, maximum speed, etc.
- 3 Enter your vehicle's previous odometer mileage, or reset the value here.



THEMES:

- 1 Press **"ELITE DASH THEMES"** on the home page the following page will appear on your screen.
- 2 Press **"PREMIUM THEMES"**, to view the themes you have purchased from our website, including new and updated.
- 3 Under **"RECENT THEMES"**, you can view the themes you recently downloaded from the Premium section.

Note: After purchasing the premium themes go to the settings and synchronize the page, the user will get updated in their account section and the newly purchased theme will appear in the Elite Dash Themes.



KEYPAD:

Introducing our latest innovation: Built-in keypad for direct communication with the ECU via CAN, providing enhanced control.

Our BT keypad offers seamless Bluetooth connectivity for MaxxECU users, while our CAN keypad provides compatibility for non-MaxxECU BT users, allowing for easy switching between modes.

The Keypad is equipped with convenient shortcuts, allowing you to effortlessly navigate with your dashboard. With just one click, you can return to your previous theme, access the color slider, or open the debug data view, providing comprehensive ECU readings on a single page.

MaxxECU BT Keypad Features:

One 3-position Turbo Boost Selector, One 10-position Tune Selector, eight on/off switches to experience unparalleled control.

CAN Keypad Features:

Offers two 3-positions switches, three hold-value switches, and eight on/off switches, providing precise control and customization options to your needs.



Additionally, easily to toggle between manual and sensor gear readings for enhanced control and title/icon customization.



KEYPAD EDIT:

» With Keypad Edit in the main menu, users can personalize button text to suit their preferences. Additionally, built-in icons providing flexibility to change keypad icons enhancing user customization and usability.



» Enjoy control, flexibility and customization with EliteDash.



GAUGE CUSTOMIZATION:

» A feature designed to put you in control
Accessible through our main menu, Gauge Customization allows users to personalize their dashboards like never before.

» Edit title text, data sources, smoothing, icons, and values effortlessly to tailor your dashboard to your unique preferences.



COLOR SLIDER:

» Your Dashboard, Your Style: Easily adjust gauge glow, color brightness, bar color, line color, and gauge color to match your preferences.

» Personalize your dashboard colors like never before.



E-12




SETTINGS:

» Press “**APP SETTINGS**” on the home page the following page will appear on your screen.

Users can customize different settings:

- **Data source:** This section can also be seen inside the Connections mode.
- **Trip logs:** Users can save their trips and add oil maintenance service.
- **User settings:** It shows the user's account details that are logged in and synchronize when a new theme is purchased so the users get updated in their account section and appear in the gallery.
- **Dash notification:** Select the checkbox to enable specific dashboard notifications.
- **Unit & Values:** Under this section, users can have a quick view of different options, e.g., speed units, distance units, vehicle speed source, temperature units, power units, time format, pressure/weight units, date format, and fuel consumption display, etc. there are more options that the users can check by going to the next page.
- **Data Multicast:** It is used to cast or accept inputs of your data.
- **LDS settings:** This service sends live data to a web page this is primarily meant for hobbyist racers to be able to monitor the vehicle data from the pits while the car is on the race track.
- **Application settings:** click to see application options.



EDIT VIEW & QUICK SETTINGS:

- 1 The **"EDIT VIEW"** option can only be used by admins.
- 2 Access **"QUICK SETTINGS"** by tapping the button at the bottom centre of the screen.
- 3 Choose Quick Settings: Start or stop datalogging, read or clear error codes, reset Trip A or Trip B, reset service notifications, and start navigation.



SYSTEM SETTING

» The Elite Dash System Settings allow you to configure and save the following options:


- » Signal Lights Camera – ON/OFF
- » Front Camera Flip / Mirror
- » Reverse Camera Flip
- » Reverse Camera – ON/OFF
- » Launch Control Blinker – ON/OFF
- » RPM Intro Logo – ON/OFF
- » RPM Blinker – NEW / OLD / OFF
- » Screen Brightness Settings
- » Color Settings Button
- » Keypad Settings Button

Brightness Setting:

Set separate brightness levels for Day and Night, based on whether the Low Beam is ON or OFF. By default, Day brightness is set to 100% and Night brightness to 0%.

Intro Logo:

When enabled, the Intro Logo appears when the RPM is at 0 or the engine is OFF.



SHORTCUT BUTTONS

» Each Elite Dash theme includes different hidden shortcut buttons across its pages, allowing you to quickly navigate between pages, change colors, access settings, and swap widgets. By default, buttons 1–6 are the primary navigation shortcuts:




- | | |
|--------------------|--------------------|
| 1. Previous Page | 4. Color Settings |
| 2. Next Page | 5. System Settings |
| 3. Keypad Settings | 6. Camera Page |
| | 6.1 Map Page |

» Other numbered buttons vary depending on the theme and may be used to swap widgets, change RPM or speed gauge styles, or reset Trip A, Trip B, and current trip data.

Shortcut functions differ between themes. You can view the “Shortcut Button Functionality” images for each theme on our website:

E-10 Themes: elitedash.ae/themes/e-10-dash/

E-12 Themes: elitedash.ae/themes/e-12-dash/





**THANK YOU
FOR USING
ELITE DASH**



+971 58 999 8016



contact@elitedash.ae



@elitedash.ae



Warehouse # 2 – 26th St, Alqouz 4,
Dubai, United Arab Emirates

www.elitedash.ae